Basic Installation Instructions The Aquasana shower filter easily installs in minutes.

Remove your existing shower head. Attach the filter system to the shower supply pipe.

Flush with cold water into a large container until clear.

Attach the shower head to the filter body.